



SADDLE CONNECTION ON EXISTING SANITARY SEWER

NOTES:

1. SADDLE TO BE INSTALLED IN 10:00 OR 2:00 POSITION.
2. EXISTING SEWER MAIN SHALL BE TAPPED WITH HOLE SAW.
3. SEALTITE SEWER SADDLE, SHALL BE AS MANUFACTURED BY GENECO.



CADD FILE: \\standard\details\sewer\sc001.dwg			
DATE: 3-3-2000	DRAWN BY: DTN	PAGE: 1 OF: 1	
REVISION:	DATE:	BY:	